

Coway Air Purifier AP-1008DH

- This product is for domestic use only. It cannot be used in an overseas country where the power voltage is different.
- Warranty card is included in this user's manual.
- Read and save these instructions



FEATURES


1. MCC™ medium filter

This is a versatile filter which removes the yellow dust that occurs during the spring season as well as toxic gases, viruses and bacteria such as influenza, legionella, etc.



2. Pollution level indicator/ mood lamp


It has the function showing in the pollution level indicator by sensing the pollution of the indoor air automatically and added up to the interior-wise function.



3. Power saving mode

AS the fan is automatically turned on/off according to the pollution level of the surrounding area, it helps the electricity saving for continuous operation of the product.

* Available only in auto mode operation.



4. Slim design

The slim design makes the product fit well in any place in harmony with the surroundings.



DEAR CUSTOMERS

Thank you for using the **coway air purifier**.

Please read the user's manual to use and maintain the product correctly.

If you encounter a problem while using the product, you may easily solve the problem by referring to the user's manual. As this manual contains the product warranty card, please keep it in a safe place.

CONTENTS

FOR INFORMATION

| 03 | SAFETY INFORMATION

Danger

Warning

Caution

| 07 | PARTS NAME

| 08 | AIR PURIFIED PROCESS

MAINTENANCE

| 16 | CLEANING METHOD

Product

Filter

| 18 | FILTER REPLACEMENT

HOW TO USE

| 09 | PREPARATIONS

How to Install Filter

| 10 | OPERATION/INDICATION PART

| 13 | HOW TO USE

| 15 | ADJUST PARTICLE SENSOR

OTHERS

| 19 | TROUBLESHOOTING

| 20 | SPECIFICATION

| 21 | WARRANTY CARD

- Please keep the User's Manual where it can be readily reached or found. -

SAFETY INFORMATION

The following information is for user safety that should be observed.

It is to ensure user safety and prevent property damage. Please read the precautions carefully and use the product correctly.





for 220 V - 240 V~ use only for 120 V~ use only

▲ Danger: If not observed, serious injury or even death could occur.

- Do not use a damaged power plug or loose electric outlet.
- Make sure to connect the power plug to a dedicated electric outlet for $220 \text{ V} - 240 \text{ V} \sim 50 \text{ Hz}/60 \text{ Hz}$.
- Do not move the product by pulling the power cord.
- Do not handle the power plug with a wet hand.
- Do not forcibly bend the power cord or run it under a heavy object to prevent it from being damaged or deformed.
- Do not plug in and plug out the power plug repeatedly.
- If the electric outlet is wet, carefully unplug the product and let the electric outlet completely dry before subsequent use.
- Unplug the product before repair, inspection, or parts replacement.
- Remove any dust or water from the power plug.
- Do not plug into an electric outlet or power strip that is being used by several other appliances. Use an electric outlet dedicated to the product.
- Unplug the product if it is not to be used for a long time.
- Do not attaempt to repai or modify the power cord.
- If the power cord is damaged, do not replace the cord yourself. Call coway service center to have it replaced.
- Do not install the air purifier near a heating device.
- Do not place the product on top of an electrical appliance such as a heater or tv.

- Do not install the product in areas where moisture, dust or water (rainwater) is present.
- Do not use the product in areas where flammable gases or combustible materials are used or stored.
- Do not stick sharp objects such as a screw driver into the pollution sensor unit.
- If the air purifier produces a strange noise, burning smell, or smoke, immediately remove the power plug from the electric outlet and call our service center.
- · Never put the product in water.
- Do not spray any flammable materials such as insecticides or fragrances to the air inlet.
- Do not disassemble, repair, or modify the product.
- Do not place on top of the product any containers with water, medicine, food, any metallic objects, or any flammable material.
- Unplug the product before you clean it.
- Do not clean the product by applying water directly to the product or using benzene or thinner.

▲ Precautions related to synthetic leather decoration

- 1. Touching the surface with a hot object or placing a hot object near the surface may cause deformations or discoloration.
- 2. When the surface is contaminated, clean it with a soft cloth to remove the pollution source. If the pollution source is not removed, dilute a neutral detergent with no additional function (such as bleaching, sterilization, anti-bacteria) with enough water and clean the polluted source with a damp cloth and then remove the detergent completely.
- 3. Do not clean the surface with an organic solvent (alcohol, thinner, acetone, etc.) and do not expose the surface to an organic solvent. This may damage the surface.
- 4. Since sharp objects may damage the surface, take care when handling such objects.
- 5. Do not store the product in a humid, cold or hot location for long periods.
- 6. You must avoid cleaning the synthetic leather by dipping it into liquid (water or neutral detergent solution).
- 7. Take care to not pollute the surface with a highly polluted substance such as a ball-point pen or marker.
- 8. If exposed to humidity for a long time, it may deform the surface.

SAFETY INFORMATION

▲ Warning: If not observed, serious injury or property damage could occur.


- Do not stick fingers or foreign objects into the air inlet or outlet.
- Do not let children hang on to the product or climb on it.
- When removing the front cover, exercise caution not to have part of you body or other objects stuck in the upper part of the product.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance can be used by children aged from 8 years and above.

Caution: If not observed, slight injury or property damage could occur.

- Do not install the product on a sloped floor.
- Do not exert excessive force or shock on the product.
- When the product is in use, maintain a distance of at least 20 cm from walls or adjacent objects and 30 cm - 60 cm above the product.
- Install the product where no obstacles around the product block the circulation of air.
- Use the air purifier away from lighting devices or direct sunlight.
- Install the air purifier at least 2 m away from electronic products such as tv.
- Do not use the product in areas where it will be subjected to heavy smoke, odors, or oil.
- Do not use the air purifier in a location exposed to direct sunlight.
- Replace filters with new ones according to filter replacement cycles.
- Clean the pre-filter with water regularly and dry completely before use.
- Do not push or lean against this product, as it may topple over the product.
- Never let children insert their hands into the hole.

PARTS NAME

Front / Rear



Others



User's manual

AIR PURIFIED PROCESS

■ Pre-filter

Treated with antibacterial materials, the pre-filter removes relatively large dust, mold, human hair, pet hair, and others.

■ MCC[™] medium filter


This is a versatile filter which removes the yellow dust that occurs during the spring season as well as toxic gases, viruses and bacteria such as influenza, legionella, etc.

■ Deodorization filter

By applying the activated filter that remove odor and the harmful gas effectively, it eliminates food odors and unpleasant household smells.

■ HEPA filter

The high-performance composite HEPA filter effectively removes fine dust and cigarette smoke while the antibacterial and anti-mold functions of organic antibacterial materials eliminate germs and mold.



PREPARATIONS

Please Check Before Use!



The product is for 220 V – 240 V \sim 50 Hz/60 Hz only.

Make sure to connect the power plug to a grounded electric outlet (220 V - 240 V~ 50 Hz/60 Hz) dedicated to the product.




How to install filter



- Make sure to remove each filter's plastic packing before installing filters.
- The product is for household use. Use the product indoors only.
- When the product is not in use, remove the power plug from the electric outlet.
- When installing filters, check that the front side of filters is in the correct direction.
- ▶ Order of filters: Pre-filter → MCC™Medium Filter → Deodorization filter → HEPA filter

1. Open the front cover.


Open the front cover by pulling the upper part of it.






2. Take out filters and remove the plastic packing.


Remove the plastic packing of the filters except the pre-filter and then install filters according to the order of filters.





OPERATION / INDICATION PART

Indication Part





1 Light sensor

It is a sensor that detects light.






2 Speed indicator

By using the speed button, it is possible to select the airflow speed in 4 steps. (Step 1 \rightarrow Step 2 \rightarrow Step 3 \rightarrow Turbo)

st When the product is in sleep mode and power saving mode, the airflow speed indicators are not turned on.

OPERATION / INDICATION PART

Operation Part





1 Power button and its indicator

Use it to turn the product on/off. When the power is on, the indicator is turned on.

* To turn off the power, press and hold the power button for approximately 1 second.



2 Auto mode button and its indicator

Use it to select the automatic operation mode. When the auto mode is selected, the indicator is turned on.



3 Mood button and its indicator

Use it to turn mood lamp on/off. When mood lamp is turned on, the indicator is turned on.



4 Silent mode button and its indicator

Use it to select the silent operation mode.
When the silent mode is selected, the indicator is turned on.




5 Speed button and its indicator

Use it to select the desired airflow speed.

* Pressing the speed button in Auto, or silent mode makes the product immediately switch to manual mode.

It displays the current cleanliness (pollution) level of the room.













Clean:Blue Lightly polluted: Polluted: Light purple Dark purple

Highly polluted: Red

* The cleanliness (pollution) level of the room is determined by the color at the end of the penetrating hole.


HOW TO USE



- Before operating the product, connect the power plug to a dedicated electric outlet.
- Once the power is turned on, you will see the previously used operation mode, already set for you to use.


■ To operate the manual mode

Press the power button and then select the speed of the wind by pressing the speed button.



■ To select the auto mode

Press the power button and then select the auto mode button.



► Auto mode

Auto operating mode sets the wind speeds (step 1, 2, or 3) depending on the air pollution states that are detected by the pollution sensor.

When the pollution levels stay in step 1 for approximately 10 minutes, the product switches to power saving mode.

In the power saving mode, the fan is turned off to minimize the power consumption and all displays except the power and auto indicators are turned off.

When the pollution level increases to level 2 or higher, the power saving mode is turned off.


When the power saving mode continues for 30 minutes, the product temporarily switches from the power saving mode to step 1 to blend the surrounding air.

	Pollution level 1	Pollution level 2	Pollution level 3 or higher	Power saving mode
SPEED	Step 1	Step 2	Step 3	Fan off

■ To operate the silent mode


Press the power button and then the silent button.

In silent mode, the airflow speed is lowered below step 1 (lower rpm), making the environment quiet and pleasant.



■ To operate the sleep mode(available only in auto mode operation)

If the surroundings are dark for 3 minutes or longer in auto mode operation, the product automatically switches to sleep mode, lowering the airflow speed, noise, and electricity consumption. If the surroundings become bright again for 5 minutes or longer, the unit resumes normal operation. In sleep mode, all displays except the power indicator are turned off.




ADJUST PARTICLE SENSOR


How to Adjust the Sensitivity of the Pollution Sensor

When the product is shipped out, the pollution sensor is set to standard sensitivity. If the pollution level stays at the highest level after 2 hours of operation or stays at the lowest level for more than 1 hour when the air does not seem clean, users can adjust the sensitivity of the pollution sensor as follows.

1. With the mood mode button pressed down, insert the power plug in the electric outlet.




2. With a tone ringing twice, the current sensitivity indicator of the sensor blinks.




3. Adjust the sensitivity by pressing the speed button. The sensitivity of the sensor is displayed by ablinking airflow speed indicator.

Sensitive	Standard	Insensitive
Speed step 1	Speed step 2	Speed step 3

4. After adjustment, the sensitivity of the pollution sensor is set when the power button is pressed to turn the product off or automatically set when 20 seconds have passed in the setting mode.






CLEANING METHOD




- Always unplug the air purifier before cleaning the product.
- Do not use detergents that contain organic solvents (solvent, thinner, etc), bleach, chlorine, or abrasives.
- Do not put the air purifier in water or spray water directly on it.

■ Cleaning the pollution sensor (every 2 months)


 Open the pollution sensor cover on the right-hand side of the product. Clean the air inlet and outlet vent and then the pollution sensor with a soft brush or vacuum cleaner.





- 2. Wet a cotton swab lightly and clean the lens, dust inlet, and dust outlet. Clean them with a dry cotton swab to remove remaining moisture.
 - $\boldsymbol{\ast}$ Without regular cleaning, the performance of the pollution sensor deteriorates.
 - * The cleaning cycle differs depending on the operation environment.


 When using the product in a dusty environment, clean the sensor more often.



■ Cleaning the air inlet and outlet (every 2 months)

Clean the air inlet and outlet with a soft brush.


* Exercise caution not to have dust fall inside the air purifier.



■ Cleaning the front cover

Separate the front cover from the product and remove the dust attached to the surface with a soft dry brush or cloth.


* Use lightly wet cloth if the contamination is serious but do not use abrasives.



■ Cleaning the product body (every 2 ~ 4 weeks)

Use dry, soft cloth to clean the product.

 \ast Use lightly wet cloth if the contamination is serious but do not use abrasives.



15

16

CLEANING METHOD




- Always unplug the product before cleaning the filter.
- The pre-filter is reusable by removing dust or cleaning it with water.
- If the pre-filter is not cleaned for a long time, the product performance may deteriorate.
- The HEPA filter are not reusable with cleaning. Never clean them with water.

■ Cleaning the pre-filter (every 2 \sim 4 weeks)

1. Open the front cover by pulling out the end part above the air inlet.






- 2. Take out the pre-filter by pulling out on the handles.
 - * To prevent dust from falling off, remove the filter carefully without exerting a shock.



3. Clean the pre-filer with a vacuum cleaner or with water depending on the level of contamination.



- 4. Install the pre-filter after removing the moisture completely. Fit the front cover back to the product.
 - $\boldsymbol{\ast}$ When refitting the pre-filter to the product, fit it in the hook correctly.



FILTER REPLACEMENT

■ How to replace filters

- Check that the 'front' sides of filters are in the correct direction.
- To maintain optimal performance of the product, use original coway filters.
- Always unplug the air purifier before replacing filters.

■ Filter cleaning and replacement cycles

Filter	cycles	method
Pre-filter	Every 2 ~ 4 weeks	Cleaning and washing
MCC™medium filter	Every 4 months	Replacement
Deodorization filter	Every 12 months	Replacement
HEPA filter	Every 12 months	Replacement

^{*} Each service life is based on 24-hour use in Speed step 1.

■ Filter replacement indicator

- 1. Button indicator is turned on one by one clockwise when the filter needs to be replaced.
- 2. Airflow LED indicates a filter that needs to be replaced.

Step 1 LED: HEPA

Step 2 LED : deodorization, Step 3 LED : MCC[™]medium


- 3. When the filter replacement indicator is displayed, the pollution level indicator is turned off.
- 4. The filter replacement indicator is displayed for 5 minutes in every half an hour.
- 5. After replacing filter, push the Reset button one time.
- 6. When you have replaced a filter before the filter replacement cycle is reached, press and hold the RESET button for 1 second(forcible reset). The forcible reset initializes all the filter replacement cycle counters.

■ Replacing filters

1. When replacing filter, check that the front side is In the correct direction.



2. With the power is on, press the reset button with a sharp tool.



17

18

st The recommended filter replacement cycles may differ depending on the operating environment.

TROUBLESHOOTING

The air purifier may operate abnormally not because of the product malfunction but because of minor causes or the fact that the user is not familiar with the product use. In such a case, problems can be solved easily even without the help from the service center just by checking the following. If the problem still persists after you check the following, contact the service center.

Symptom	Check	Measures to take
	· Is the power cord connected?	Connect the power cord to an electric outlet for 220 V – 240 V~ 50 Hz/60 Hz.
	· Is the display part all turned off?	Press the power button and then select the desired function.
No air is blowing.	· Isn't the power gone out?	Use the air purifier after the power comes back on.
	· Is the auto mode indicator turned on?	When the pollution level 1 lasts continuously for 10 minutes, the product switches to power saving mode, turning off the fan automatically.
The airflow speed	· Isn't it in manual or silent mode?	Set the desired operating mode.
does not change.	· Isn't the room dark?	When in sleep mode, the airflow speed is fixed to the minimum level.
The airflow speed is significantly weaker than before.	· Isn't the filter cleaning or replacement time passed?	Check the filter cleaning and replacement cycles and then clean/replace the filter(s) if necessary.
A bad smell comes out of the air outlet.	· Isn't the filter cleaning or replacement time passed?	Check the filter cleaning and replacement cycles and then clean/replace the filter(s) if necessary.
The color of the	· Isn't there dust on the pollution sensor's lens?	Clean the lens of the pollution sensor.
pollution level indicator always stays	Does the pollution level keep indicating a high level?	Adjust the sensitivity of the pollution sensor to Insensitive or standard.
the same.	Does the pollution level keep indicating a low level?	Adjust the sensitivity of the pollution sensor to sensitive or standard.
The pollution level indicator blinks.		
When other functional problems are detected. • Check the symptoms, unplug the product, and then request service service center.		uct, and then request service or ask

SPECIFICATION

Product specification	Air Purifier
Model	AP-1008DH
Rated voltage	220 V – 240 V~ 50 Hz/60 Hz
Phase	1
Power consumption	47 W
Product insulation grade	Grade 2 device □
Dust collection mode	Mechanical dust collection method (HEPA filter)
Safety feature	Power is shut down when the front cover is opened.
Installation place	Indoor use
Maximum volume of air	5.0 m³/min
Size	354 mm(Width) \times 194 mm(Depth) \times 645 mm(Height)
Weight	7.3 kg

[▶] The specifications are subject to minor changes to improve the product performance.

WARRANTY CARD OR WARRANTY LETTER ONE YEAR LIMITED WARRANTY AIR PURTFIER AP-1008DH ("PRODUCT")

Model:

Serial Number: Customer Name: Date of Purchase:

("OWNER")

What This Warranty Covers:

Commencing with the date of purchase of the Product and continuing for a period of one year, if manufacturing defects in the Product cause the Product to not operate properly for its intended use, then subject to the exclusions, conditions, and limitations contained herein, COWAY at its sole option will repair or replace the Product.

Decisions as to the extent of repair or replacement required will be made solely by COWAY.

The remedy under this Warranty is available only for that portion of the Product exhibiting defects at the time of the warranty claim. The replacement Product as well as any remaining original Product will be warranted only for the original one year warranty period. This limited warranty applies only to Product used for an application specified by COWAY for the Product and applied in strict accordance with COWAY published specifications in effect at the time of application. IF PRODUCT IS USED FOR OTHER THAN ITS INTENDED PURPOSE, IT IS SOLD AS IS AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

What This Warranty Does Not Cover:

This Warranty warrants that the Product will be free from manufacturing defects which affect the ability of the Product to operate for its intended use; it is not a warranty that the Product will never require repairs or to undertake responsibilities, liabilities or obligations other than those specifically identified in the preceding section. COWAY is not responsible or liable for personal injury or property damage of any kind, even if arising from a breach of this Warranty.

Limitations and Exclusions:

TO THE EXTENT PERMITTED BY APPLICABLE LAW, COWAY DISCLAIMS ANY OTHER WARRANTY EXPRESS OR IMPLIED, THAN THAT PROVIDED FOR HEREIN. THIS WARRANTY IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, GUARANTEES, CONDITIONS AND REPRESENTATIONS, EXPRESS OR IMPLIED, ORAL OR WRITTEN, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY IMPLIED CONDITIONS OR WARRANTIES AS TO THE MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE COWAY PRODUCT. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. **COWAY DOES NOT AUTHORIZE ANY PERSON** INCLUDING ITS REPRESENTATIVES, TO MAKE ANY REPRESENTATION OR TO OFFER ANY WARRANTY, CONDITION OR GUARANTY IN RESPECT OF THE PRODUCT OTHER THAN THIS WARRANTY. THIS LIMITED WARRANTY SHALL BE THE OWNER'S SOLE AND EXCLUSIVE REMEDY AGAINST COWAY AND COWAY SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, EXEMPLARY, SPECIAL, INCIDENTAL OR OTHER DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, AND LOSS OF USE. INCIDENTAL, CONSEQUENTIAL AND EXEMPLARY DAMAGES SHALL NOT BE RECOVERABLE EVEN IF THE REMEDIES OR THE ACTIONS PROVIDED FOR IN THIS WARRANTY FAIL OF THEIR ESSENTIAL PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. COWAY SHALL NOT BE LIABLE FOR ANY DAMAGES WHICH ARE BASED UPON NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY OR ANY OTHER LEGAL THEORY OF LIABILITY OTHER THAN THE EXCLUSIVE LIABILITY SET FORTH IN THIS WARRANTY.

Limitations on Implied Warranties:

Any implied warranty of merchantability or fitness for a particular purpose or use, shall be limited to the duration of the foregoing express written warranty.

Conditions of Warranty:

COWAY's continuing liability under this Warranty is conditioned upon the following:

- a) The defect or damage is not caused by or is the result of: abnormal use or conditions; improper storage, unauthorized modifications or repair; misuse, neglect, accident, alteration, improper installation or other acts that are not the fault of Coway or the manufacturer of the product or that are not covered by the manufacturer's warranty;
- The Product has not been altered, modified or repaired without prior written approval of COWAY;
- c) The OWNER has notified COWAY in writing of any failure of the Product covered by this Warranty within thirty (30) days following such failure;
- d) There has been no misuse, abuse or negligence with respect to the Product on the part of the OWNER.

Waiver:

COWAY's failure at any time to enforce or rely upon any of the terms or conditions stated herein shall not be construed to be a waiver of its rights hereunder.

Obtaining Warranty Service and OWNER'S Duties:

If the Product fails to operate for its intended purpose, then notify COWAY or its Representative Agency, within 48 hours or within the next business day after discovery of any defect in the Product. The OWNER must give written notice to COWAY no later than thirty (30) days after a defect is discovered or should by reasonable diligence have been discovered. Claims under this Warranty will require proof of purchase by the OWNER.

COWAY

Add: Coway co., Ltd.

136-23, Yugumagoksa-ro, Yugu-eup, Gongju-si,

Chungcheongnam-do, Korea Tel. : 82-41-850-7879

Fax. : 82-41-841-7816

THAILAND

Add: COWAY(THAILAND) CO., LTD.
571,R.S.U TOWER 4-5 TH FL.,SUKHUMVIT31
KLONGTON NUA, WATTANA BANGKOK,
THAILAND ZIP CODE:10110

Call center: 001-66-2-661-8620

USA

Add: WOONGJIN COWAY USA.INC

695 S VERMONT AVE. #110, LOS ANGELES, CA,

90005

Call center. : (213) 386-9900 / (213) 480-1600

Fax. : (213) 386-3990

MALAYSIA

Add: COWAY (M) SDN BHD

SUITE 6-3 & 6-4 LEVEL 6, WISMA UOAII NO.21 JALAN PINANG 50450 KUALA LUMPUR

kuala Lumpur

Call center: 1-800-888-112

21

22



coway

www.coway.com













